


Drawing View Caption


This Tech Tip looks at changing text properties in a drawing view.

Have you ever wondered how to change the properties on both lines of text on a drawing view?

In this case, we have opened the Properties on a drawing view and change the caption format to be 10mm, but why has it only changed the first line?



To change the font size on the second line, change the Caption type to Second Caption and change the font size there too.



DETAIL A
4:1